

One-Pager guide CS02

1. Connect the hoses between engine and CS02
2. Switch on the fully charged CS02 and wait for continuous green LED.
3. Connect with WLAN CS02
 - Password for first connection : ADK-2023
 - Start browser (e.g.Chrome) and enter: 10.4.5.58 then gauge will come to screen.
4. Start synchronisation at 2000-2500rpm
 - If hoses are correct connected, needle moves into the direction of the throttle which needs to be opened.
 - CS02 recommendation can be inverted: if opening of left side is proposed, you can also close right side.
5. Synchronize the idle position.
 - Turning the Idle screw clockwise increases pressure and speed